

Can I change the orientation of the panels on a flat roof?

Yes, you can. Horizontal and portrait panels will automatically be angled toward the “bottom” or “gutter line” of the roof whether flat or ground-mounted. In roof outline mode, the “bottom” of the roof is the first side you draw. In quick roof mode and 3D design mode, the “bottom” of the roof is based on how you set the orientation of the roof.


If you want to change the angle of the panels, you’ll need to change the orientation of the roof. For a standard flat roof, the panels will orient towards the yellow circle:




If you want to orient the panels another way on a flat roof you can use the irregular roof tool and the following steps:

Note: this option is only available when using the 3D design mode.


1. Select the 'Irregular building' option in **Misc.**




2. Set the roof type to flat by clicking on the roof and selecting from the mini-menu



and the pitch to 0 in the elevations view




3. Size and reshape the roof to the necessary roof - if needed you can fix the angles of the corners by clicking on the corner and selecting the option highlighted in blue below.



4. Drag the blue dot to direct the arrow, the arrow points in the direction of the panels.



Then when you enter the panels task, the panels will face the direction specified:



Revision #9

Created 30 September 2024 14:38:59 by Daisy Kernick

Updated 26 November 2024 15:07:04 by Daisy Kernick