

I added a hybrid inverter to 'My Components' but can't add a battery to it in the inverter task.

If you are trying to use custom hybrid Inverter and battery components - you will need to make sure you have added the battery as its own component. This is true even for all-in-one systems.

You can do this under **Components > Edit Batteries**. For more detailed instructions, take a look at our [guide to setting up batteries in Easy PV](#).

Revision #6

Created 5 September 2024 16:50:41

Updated 14 May 2026 10:18:40 by Daisy