

Setting Up Speedy PV


Speedy PV is an instant estimate and lead generation tool that can be embedded in your website to allow your customers to get an immediate indication of the suitability of their property for solar, and an indicative price. Leads generated by the tool are imported into Easy PV so that you can turn them into projects.

Below you'll find a helpful video walking you through the setup process. Further down, you'll find written instructions too, so you can easily refer back to this page whenever you need.

<https://www.youtube.com/embed/BIQ3n14fjrc?si=fvnGAYXHO1DAvM2L>


Enabling the tool in Pro Account Settings

To configure Speedy PV, navigate to **Pro Account Settings** and go to the **Speedy PV Beta** tab. Then enable the Speedy PV configuration dashboard.



The screenshot shows the 'Pro Account Settings' page. The left-hand navigation menu has 'Pro Account Settings' highlighted with a red box. The main content area is titled 'Team Preferences' and has four tabs: 'General', 'Financial', 'Email', and 'Speedy PV Beta'. The 'Speedy PV Beta' tab is selected and highlighted with a red box. Below the tabs, the 'Speedy PV Beta' section is visible, containing a description of the tool and a toggle switch labeled 'Enable the Speedy PV configuration dashboard', which is also highlighted with a red box.

Then a new option will appear on the left-hand side. Click this and you will be able to work through all the tabs to set up your Speedy PV.



Setting up website domain

Start by putting in the website domain for the websites you want to host the tool on. If you would like to embed it in more than one website, then add an additional row to your list of URLs. If you would like to remove a domain, click the option highlighted below.

Please note you only need to include the *domain* of the website, not the full address. For example, if the tool will appear at "www.mywebsite.com/my-speedy-pv" then you only need to input "www.mywebsite.com" into the URLs section.

Contact details

On the contacts tab, put in the details for people to use when they need to contact you for more information. These will usually be your main office or sales phone number and email address.

Appearance

On the appearance tab, you can set the primary colour to use for the iconography colour scheme and any buttons in the tool.

To do this simply add in the Hex code for the colour you would like to use in the box outlined below and make sure it looks correct in the preview.

If you haven't used hex codes for colours before, don't panic! You can find a [colour picker here](#) where you can find the colour you want for your tool, and turn it into a hex code.


Theme Colour

Select a colour to customise the appearance of the Instant Estimate tool and to make sure it aligns with your brand. Choose a colour that isn't too dark - it's important that black text is clear against a background of this colour.

Colour (Hex format)

FFA500

Preview



Emails

On the emails tab you can add an email signature that will appear at the bottom of the emails that are sent by the system.

You can optionally configure SMTP email credentials for one of your email addresses so emails will be sent from that address instead of a no reply at EasyPV email address.

You can also add in other email addresses to copy in on the emails that are sent so that could be an email for your sales team or another generic mailbox.

Pricing settings

To use Speedy PV, you must set up automatic pricing rules, so the correct estimates can appear for your project. If automatic pricing is already set up then nothing needs to be changed here.

If automatic pricing is not already set up then you can follow these steps on our [guide](#).

Estimate configuration

In this section, you set defaults for which panels and inverters will be used in the estimates Speedy PV generates.

Select from the drop down menu which panel you want the quotes to be based on. If left blank, the tool will default to using "Jinko Tiger Neo 440W N-Type All Black Mono" in estimates.

In the inverter selection, you can choose up to three inverter groups you would like the tool to pick from in estimates. The tool will use inverters from your chosen groups in order of preference, whenever suitable for the generated PV system. If not filled in, the tool will default to using the groups "GivEnergy (Hybrid)", "Huawei (Hybrid)", "Growatt".

Terms

On the terms tab, read through the specific terms for Speedy PV and once you're happy, click I accept the terms of use.

Billing

On the billing tab you will need to accept the billing conditions.

Test page

Once the previous sections have been completed, you can play around with a test page. This has the option of testing with the desktop or mobile version.

Go Live

On the 'Go Live' tab, you will be able to see the following checklist:

Checklist

- ✓ Domain entered
- ✓ Contact details entered
- ✓ SMTP credentials entered
- ✓ Automatic pricing has been set up
- ✓ Panel selected
- ✓ Terms accepted
- ✓ Billing plan accepted

If any required sections are not completed, go back and fix any errors. Once all required fields are checked and you are happy with everything, you can then embed the tool into your website by following the instructions in this article: [Embedding Speedy PV into your Website](#).

Once that's all done, you can then start using the tool in your website! If you have any questions, please contact our support team at help@easy-pv.co.uk.

Revision #9

Created 6 September 2024 16:49:48

Updated 5 March 2026 13:33:21 by Daisy