I have selected a custom inverter and it isn't showing the right number of strings. How do I fix this?

On each inverter, you can see:

1. The number of MPPTs (inputs)
2. The number of strings on each MPPT



If the number of **MPPTs** is incorrect, you need to add more trackers in the **Solar** section of your custom inverter. The number of inputs will correspond to the number of trackers in this section.



If the number of **strings** is incorrect, you either need to adjust the number of allowed strings or check the current value in the **Solar** section of your custom inverter.



Revision #8
Created 12 May 2026 12:37:03
Updated 16 October 2026 14:43:06 by Emma Gough