
How can I model an east-west panel layout?


To model an east-west panel layout, create a flat roof or ground mount area in any design mode.

In the panels task follow these steps:


1. **Add panels** to the roof/area and then **select 'No mounting'**
2. Set the direction to **east-west** and configure the spacing as needed



3. Select option 1 to fill the roof/area with portrait panels, option 2 to fill the roof with landscape panels and 3 to clear the roof



Or drag and drop portrait (right) or landscape (left) panels to build panel layout



> This will not spec the mounting components but will mean the pitch and orientation of the panels is correctly modelled in performance calculations. Get in touch with Midsummer (UK) / (IE) for guidance on mounting components.

Revision #7
Created 19 November 2025 15:44:36
Updated 14 October 2026 16:30:14 by Emma Gough